

Air Precleaner Installations Instructions for the M988 series

1. Check contents to ensure all components are in the kit and are in serviceable condition.

Kit Contents

Qty	Nomenclature
1	9001 air precleaner
1	40RA45 rubber adapter
2	worm gear clamp
1	DVP Plug



2. Remove rain cap from on top of the air inlet on the front passenger side of the vehicle



3. Slide the smaller (narrower inlet) end of the black rubber adapter on the Sy-Klone precleaner and secure with one worm gear clamp. To install the worm gear clamp loosen and slide over the black rubber adapter and use a regular screwdriver (or a 5/16th wrench) to tighten the clamp in place.

Note: Ensure the rubber adapter is tight against the prescreen before tightening the worm gear clamp.

4. Loosen and slide the second worm gear over the rubber adapter. Do not tighten!



Continued on reverse side

5. With the precleaner and adapter assembly and the lower worm gear clamp loose slide this assembly over the air inlet pipe on the hmwv.

Note: The precleaner can be installed on vehicles both with and without the extension pipe for the fording kit.

6. Slide the loose clamp down around the base of the hose and tighten with a regular screwdriver ensuring that the hose clamp is securing the assembly to the air inlet pipe.



Precleaner with Fording Kit extension



Precleaner without Fording Kit extension

7. Next remove screws holding the cover plate under the passenger side wheel well. This is the cover plate allowing access to the underside of the air filter canister housing where the dump valve is located.

Note: Arrows indicate three of the screws. View of fourth screw is obscured by tire in this photo.



8. Remove the dump valve or the fording plug (Which ever is present) and discard. Insert the DVP from the kit into the dump valve tube.

9. Use a 9/16-size wrench to tighten the nut on the DVP plug until snug.



10. Replace the protective plate with the four screws securing it in place.

11. Please dispose of all garbage in the appropriate receptacle.

For technical support or to order replacement parts contact Sy-Klone International at 1-800-351-8265