

Air Precleaner Installations Instructions for the 800 - 900 series 5-ton Trucks

1. Check contents to ensure all components are in the kit and are in serviceable condition.

Kit Contents

Qty	Nomenclature
1	9002 air precleaner
1	60R50 rubber insert ring
1	T-bolt clamp



2. 900 Series truck - remove rain cap from the air intake, which is located behind the cab on the driver side of the vehicle.

800 Series truck – remove rain cap from air intake, the rain cap will be located on the driver side front fender.

3. After unpacking the assembly, verify that the clamp is on the outside of the throat and the rubber insert ring is located inside the throat of the precleaner. The photograph shows the proper assembly.



Continued on reverse side

4. Using the Step 3 assembly, place this assembly onto the air inlet pipe on the truck.

5. Slide the clamp down around the base of the precleaner and tighten with a 7/16" deep well nut driver or wrench. Verify that the clamp has secured the assembly. Do not exceed 65 in-lbs on the clamp.



900 Series Truck



800 Series Truck

6. Please dispose of all removed parts and packing materials in the appropriate receptacle.

For technical support or to order replacement parts contact Sy-Klone International at 1-800-351-8265