


Bulletin 200

Vacuator Valve Plug Installation Instructions

Do you want a precleaner that removes debris headed for your engine?

**Or do you want a precleaner that takes debris from the air
and throws it onto your air filter...greatly reducing filter life?**

**You must plug the hole in the bottom
of the filter housing with a Vac Plug
to get peak efficiency and longer filter life!**



INSTALLATION INSTRUCTIONS

1. Remove the rubber vacuator valve from the end of the vacuator tube (located on the air filter housing).
2. Clean inside of vacuator tube.
3. Insert a Sy-Klone Vac Plug into the vacuator tube (as shown above).
Part No. DVP-3930 for a 3" hole.
Part No. DVP-3920 for a 2" hole.
Part No. DVP-3915 for a 1.5" hole.
Part No. DVP-39125 for a 1.25" hole.
4. Securely tighten lock-nut on Vac Plug

WARNING! Do not attempt to install, remove, or inspect unit while engine is running. Do not insert objects into open areas while in operation.